





**BN1135 & MBN1105 16" BAND SAWS**32C16 UPPER GUIDE COMPLETE
(Specify for metal or wood)

Ref. No.	Part No.	Description
1	32A58	Guide Bracket and Stud
2	32-55	Guide Blocks (for metal)
	32-53	Guide Blocks (for wood)
3	32-54	Guide Block Clip (2)
4	32-75	Ball Bearing Guide Roller
5	206-2	Roller Lock Scr.
6	214-2	Front Guard Stud
7	509-1308	Rd. Hd. Scr. (2)
8	560-20	Flat Washer
9	552-20	Crown Nut
10	32-30	Guide Support Rod
11	33-18	Guide Rod Elbow
12	211A6	Guide Lock Scr.
13	525-2406	Allen Scr.

33A109 TELESCOPING FRONT GUARD

Ref. No.	Old No.	New No.	Description
1	11BN45	33C7	Wheel with Tire
2	11BN45A	33-15R	Tire
3	11BN41A	33-86R	Tension Housing
4	11BN12A	33A85R	Wheel Adj. Bracket
5	11BN42B	33A9	Shaft and Plate
6	11BN113	33-130R	Wheel Guard
7	11BN111	33-131R	Guard Cover
8	11BN43A	251-21	Spacer
9	11BN43B	251-22	Hub Collar
10	11BN41CN	33-11	Adj. Scr.
11	11BN41B	310-24R	Spring
12	11BN42C	215-7R	Pin
13	11BN35	Obsolete	Spacer
14	11BN42D	219A3R	Scr.
15	11BN42E	Obsolete	Hand Wheel
16	11BN41E	214-29R	Guide Rod
17	11BN39	226-7	Nut (2)
18	9BN37	211A3Q	Lock Scr.
19	11BN43D	243-18	Bearing Washer (2)
20	11BN42F	223-11	Lock Nut
21	7S3	370-23-1	Bearing
22	9S17	363A3-4	Wheel with Handle
23	MJ69	363A3-4	Wheel with Handle
24	CBS3A	Obsolete	Crown Nut
25	9TA14A	244-2	Key Washer
26	Comm.	560-24	Washer
27	Comm.	501-2412	Hex. Bolt
28	Comm.	560-24	Washer
29	Comm.	541-20	Hex. Nut
30	Comm.	560-20	Washer
31	Comm.	561-20	Washer
32	Comm.	501-2016	Hex. Bolt





292C6R LOWER GUIDE COMPLETE
(Specify for metal or wood)

Ref. No.	Part No.	Description
1	292A6R	Bracket and Stud
2	32-55	Guide Block (metal)
	32-53	Guide Block (wood)
3	32-54	Guide Block Clip
4	32-75	Ball Bearing Guide Roller
5	206-2	Lock Scr.
6	509-1308	Rd. Hd. Scr.

Ref. No.	Old No.	New No.	Description
1	11BN40A	Obsolete	Mainframe
2	11BN44	Obsolete	Lower Wheel
3	11BN45A	33-15R	Tire
4	11BN114	33-127R	Wheel Guard
5	11BN7L	33-118R	Drive Shaft
6	11BN59E	33-107	Collar
7	11BN46A	Obsolete	Table
8	11BN112	33-126R	Guard Cover
9	9BN37	211A3Q	Lock Scr.
10	11BN56C	33-178R	Tilt Scr.
11	11BN59D	Obsolete	Collar
12	Comm.	301-7	Key
13	11BN49B	216C11R	Lock Scr.
14	11BN57A	21-24R	Scr. Housing
15	11BN56D	21-50R	Yoke
16	11BN56E	21-51R	Tilt Scr. Nut
17	11BN72	320-8R	Ind. Point
18	11BN62	212-14R	Tilt Plunger
19	9TA37	21-3R	Table Bracket
20	11BN49A	21-4R	Table Bracket
21	11BN60A	21-6R	R. Table Bearing
22	11BN51A	21-5R	L. Table Bearing
23	11BN56G	Obsolete	Scale
24	9BN13	370-8-1	Bearing (2)
25	9S33	See Ref. #27	
26	SA7	254A19	Collar
27	9TA41	364-8	Crank
28	11BN59F	240-30	Spacer
30	50B	240-11	Washer
32	11BN56B	Obsolete	Collar
33	Comm.	545-30	Jam Nut (2)
34	Comm.	545-34	Jam Nut (2)
35	Comm.	527-3208	Set Scr. (2)
36	Comm.	561-24	Washer (2)
37	Comm.	501-2416	Hex. Bolt (5)
38	Comm.	501-2412	Hex. Bolt (3)
39	Comm.	561-24	Washer (5)
40	Comm.	501-2024	Hex. Bolt
41	Comm.	525-2005	Allen Scr. (2)
42	Comm.	501-2020	Hex. Bolt
43	Comm.	560-20	Washer
44	Comm.	562-20	Lock Washer
46	Comm.	508-1308	Rd. Hd. Scr. (2)
47	Comm.	545-20	Jam Nut
48		Obsolete	Tilt Bracket
	Not Shown	341A1	Pulley

MOTOR PULLEYS

5/8" 344A8



3/4" 344A26

REAR BLADE GUARD


33C144R

MOTOR BASE ASSY.

32C22



RIP FENCE



Machines manufacture prior to 1941 did not include Key Nos. 45, 46, 47 and 48 On this Machine Key No. 24 was a different style that is no longer available. When drive shaft (#23) must be replaced on these machines, all of the following must be replaced: Key No. 24, 25, 26 and 27.

CAT. #32C41 RIP FENCE AND BAR

Ref. No.	Part No.	Description
11	251-5	Bearing Spacer
12		Bearing, Not Available
19	370-8-1	Ball Bearing
22	344A27	Pulley (Note # 2)
23	33-132	Drive Shaft
24	32A60	Pulley Hub(Note # 3)
25	360-6	Hand Nut (Note # 3)
26	310-30	Hub Plunger Spring (Note # 3)
27	33-105	Hub Plunger (Note # 3)
28	270-6	Oil Seal
29	330C11	Reduction Idler Gear 94 T (Note # 1)
30	330C11	Reduction Idler Gear 30 T (Note # 1)
31	330A13	Reduction Drive Gear 94 T
32	344A27	Reduction Drive Gear 30 T. (Note # 2)
33	33-106	Gear Lever Cam, Incl. in 330C11
34	362-6	Gear Shift Lever, Not Ill.
35	299-8	Gear Lever Cam pin Incl. 330C11
36	377-22	Bronze Bearings
37	202-10	Gear Lever Cam Scr.
38	32-70	Shift Lever Segment, Not Ill.
39	212-13	Shift Lever Plunger, Not Ill.
40	310-21	Plunger Spring, Not Ill.
41	365-18	Hand Knob, Not Ill.
42	231-7	Locking Plug
43	230-5	Locking Plug
44	213-11	Locking Stud, Not Ill.
45	32A65	Drive Shaft Bracket
46	32-66	Drive Shaft Bracket Plug
47	370-12	Ball Bearing
48	32-67	Bearing Collar
49	33-133	Gear Housing Cover
50	32-64	Gear Housing
51	217-1	Belt Guard Stud, Not Ill.
52	501-2416	Hex. Bolt (3)
53	525-2005	Allen Scr. (2)
54	525-3205	Allen Scr. (2)
56	510-1608	Fillister Hd. Scr. (11)

Ref. No.	Part No.	Description
1	32-41	Rip Guide Carriage
2	561-28	Washer
4	501-2948	Rip Guide Bolt (2)
5	204-10	Carriage Locking Stud
6	21-40	Fence
7	320-11	Indicator Point
9	240-87	Bevel Washer
10	362-1-2	Lock Handle
11	525-1308	Scr.
12	501-2116	Hex. Bolt
8	Cat. #32C26	Rip Fence Support Bar Specify R. or L. (includes studs and nuts)

CAT. #32C24 BELT GUARD

Ref. No.	Part No.	Description
1	32-24	Belt Guard
2	32-56	Buard Bracket
3	360A2	Lock Handle
4	291-2	Bracket Pin
5	525-2406	Allen Scr. (2)

NOTE # 1

330C11 Gear Assembly includes 94 tooth and 30 tooth Id Gears assembled. Never sold separately. Also included. part numbers 33-106 Cam, 299-8 Pin and 377-22 Bush

NOTE # 2

344A27 includes 4 step pulley and 30 tooth Drive Gear assembled. Never sold separately.

NOTE # 3

32A60 Pulley Hub includes 360-6 Nuts, 310-22 Spring, 33-1 Plunger and 571-0606 Pin. When ordering plunger componen you must order nut, plunger and pin to be able to assembli